


Ship's Wheel (07-0006)

1: Place the Ship's Wheel Insert inside the Ship's Wheel.

2: Use the 7.5mm x 80mm lag screw and 8.5mm washer to fasten the Ship's Wheel to the board. Do not over-tighten or the Ship's Wheel will not turn.

(Note: board must be at least 2" thick so that the lag screw does not penetrate the other side.)

3: Place the Ship's Wheel Cap over the center of the Steering Wheel.



Please note: Ship's Wheel is intended for make-believe-play by children.

FOR RESIDENTIAL USE ONLY
FOR CHILDREN AGES 3-11